Operating Instructions for Recirculating flush toilets and hand basins.

Flush tank – 113.5L - 128.7L capacity

- Open Flush tank lid (A).Use plastic stay (on right-hand side) to hold open flush lid.
- Pour 25ml liquid (in temperatures below 25°C) or 1x Quick Scents Bio sachet into the tank.
- Pour 19L of cold water into the flush tank.
- Thoroughly mix additive and water.
- Close flush lid firmly into position (ensure lid stay is not trapped by guiding it away from support area).
- Make sure filter bag is fully submersed in the water.
- Operate pump handle or foot pump (depending on version) several times to ensure good operation (B). If toilet does not flush, check for adequate water and again ensure filter bag is fully submersed in water.
- Satellite Industries recommends that this toilet tank should be emptied and cleaned once every week, even when it is not full, to ensure sanitary conditions are maintained.

Hand Wash Basins - 32.5L capacity

- Remove the bowl top (C),
- Use watering can or hose pipe to fill basin with cold water.
- Do not overfill (water may overflow onto the floor).
- To drain old water from basin, unfasten black drain plug at base (D).
- Make sure to re-tighten drain plug before refilling with fresh water.
- Depress black pump with hand or foot (depending on version) to achieve flow of water through tap and into bowl.(E)

email: philc@satelliteindustries.com - Tel: 01827 723999
www.satelliteindustries.co.uk